



Warning: THE ASSEMBLY INSTRUCTIONS ALLOW CORRECT INSTALLATION ACCORDING TO THE USE SPECIFIED BY THE MANUFACTURER.



Warning: THESE INSTRUCTIONS ARE MAINLY MEANT FOR SPECIALIST TECHNICIANS.

BEFORE CARRYING OUT ANY ASSEMBLY OPERATIONS, CAREFULLY READ THE INSTRUCTIONS IN THIS TECHNICAL CHART FOR EACH TYPE OF STEERING WHEEL.

IN CASE THE ASSEMBLY OPERATIONS ARE NOT CARRIED OUT BY A SPECIALIST TECHNICIAN, THE PERSONS CARRYING OUT THE OPERATIONS MUST, HOWEVER, HAVE THE QUALIFICATIONS AND SKILL NECESSARY FOR CARRYING OUT STATE-OF-THE-ART ASSEMBLY OPERATIONS.

KEY

2	--
3	Rubber casing.
4	Collapsible boss.
6	Screws.
7	Horn.
8	Horn ring (optional).
9	Aluminium lens with logo.
10	--
11	Eccentric ring (optional).
12	--
13	--
14	--
15	Steering shaft.
16	Nut screws for fixing to steering shaft

TECHNICAL FEATURES OF THE STEERING WHEEL

Rim - diameter:	300/330/350/370mm
Spokes - No.:	2/3/4 spokes
Type of covering:	leather / perforated leather / suede alcantara / plyurethane

Note: Parts (15) and (16) form part of the vehicle.

